

## CP4 Cylinder head

### Criteria:

Identification

Completeness

Mechanical damage

Corrosion



## CP4 Cylinder head

### Criteria:

#### Identification

PN on core return box will be used as identification criteria

## CP4 Cylinder head


### Criteria:

#### Completeness

Assembled CP4 cylinder head with mandatory parts: Cylinder head, spring and piston



Acceptable




Acceptable

# CP4 Cylinder head

## Criteria:

### Completeness

Disassembled CP4 cylinder head with mandatory parts:  
Cylinder head, spring and piston




Acceptable

## CP4 Cylinder head


### Criteria:

#### Completeness

Disassembled CP4 cylinder head with missing components



Not acceptable



Not acceptable

## CP4 Cylinder head

### Criteria:

Mechanical damage


No mechanical damage  
allowed

## CP4 Cylinder head

### Criteria:

Corrosion

Slight corrosion is allowed



Acceptable