

Hot-wire air-mass sensor (HLM)

Criteria:

Identification

Completeness

Mechanical damage

Corrosion



Hot-wire air-mass sensor (HLM)

Criteria:

Identification

Part number must be legible



Acceptable

Hot-wire air-mass sensor (HLM)

Criteria:

Completeness

Incomplete parts are not acceptable

Hot-wire air-mass sensor (HLM)

Criteria:

Mechanical damage

- Temperature sensor (B)
- Cylinder housing, plug connector and electronic housing (exception cap A)
- Potentiometer
may not be damaged

Hot-wire air-mass sensor (HLM)

Criteria:

Corrosion

Light corrosion is acceptable